



Date and Time

To set the date and the time the terminal batch must be cleared first. The instructions are in the terminal user guide (extracted pages attached). It may ask for a password or current date and that is a trick we don't advertise. The answer will be the today's julian date x 3 = 993

Below are the instructions on how to get to the time:

It can be change through the TELLIUM MANAGER

1. On the terminal press the Yellow Key + .,#* Key – to power down the terminal
2. Press Green Key to reboot the terminal
3. As the terminal reboots, you will see screens in the following sequence:
 - o Blue Screens (hardware/software information)
 - o Black Screen (with copyright information)
 - o White Screens (hardware/software information)
 - ♣ After a few white screens asterisks will show
 - * - at the first asterisk press F Key, then F Key again – this will take you to the Tellium Manager.
 - **
 - ***
 - o If you don't press the F Key quickly enough, then you may need to do steps 1 – 3 again.

0 TELLIUM MANAGER > 3 INITIALIZATION > 1 PARAMETERS > DATE AND TIME